

TECHNISCHE HINWEISE ZUM WECHSELN DER KEILWELLENMUTTER



NUVINCI CYCLING EUROPE | Fallbrook Technologies Int. | Popovstraat 12 | 8013 RK Zwolle, The Netherlands | europa@fallbrooktech.com | www.nuvincicycling.com
NUVINCI CYCLING USA | Fallbrook Technologies Inc. | 2620 Brushy Creek Loop | Cedar Park, Texas 78613 USA | www.fallbrooktech.com

Materialien & Werkzeuge

1. Drehmomentschlüssel
2. Keilwellenmutter
3. Keilwellenmutterwerkzeug



***Nutzen Sie nur das Spezialwerkzeug für das Austauschverfahren**

Materialien & Werkzeuge

1. Drehen Sie die Keilwellenmutter gegen den Uhrzeigersinn von der Achse.
2. Setzen Sie eine neue Keilwellenmutter auf die Achse und ziehen Sie mit einem Drehmomentschlüssel bei 10Nm fest. Die Nabe ist nun bereit für die Montage.
3. Falls diese Wartung vor dem Einspeichen durchgeführt wurde, setzen Sie die Anti-Shift Befestigung zurück auf die Achse.



***Nutzen Sie nur das Spezialwerkzeug für das Austauschverfahren**

Intellectual Property Notice



This presentation and the information contained in it except information attributed to other sources are the exclusive property of Fallbrook Technologies Inc. and are protected by one or more patent, trade secret, trademark, copyright and other laws. Any reproduction, distribution, or modification of any of the content of this presentation or any of the information contained in it in any manner without the express permission of Fallbrook Technologies Inc. is strictly prohibited.

Fallbrook Technologies and their associated logos are trademarks or registered trademarks of Fallbrook Technologies Inc. and all rights are expressly reserved.

NuVinci Cycling Support and Service – Europe

Fallbrook Technologies International

Popovstraat 12
8013 RK Zwolle, The Netherlands

+49 2289 2939 079 DE Support
+41 43 508 55 97 CH Support
+31 38 7200 711 Europe General Support

nuvinci@hartje.com (DE & AT)
ch-service@nuvincicycling.com (CH)
eu-service@nuvincicycling.com (Europe)

www.nuvincicycling.com

NuVinci Cycling Support and Service – USA

Fallbrook Technologies Inc.

Cedar Park, Texas 78613, USA

1-888-NuVinci (688-4624) (USA Toll free)
Tel: +1 (512) 279-6200
Fax: +1 (512) 267-0159

support@nuvincicyling.com

www.nuvincicycling.com